

Available ratios for SL90-20 Gearbox

Gears			Ratio
35	/	24	0,686
32	/	24	0,750
31	/	24	0,774
30	/	24	0,800
27	/	22	0,815
30	/	25	0,833
27	/	23	0,852
29	/	25	0,862
25	/	22	0,880
24	/	22	0,917
28	/	26	0,929
21	/	20	0,952
27	/	26	0,963
28	/	27	0,964
24	/	24	1,000
27	/	28	1,037
20	/	21	1,050
26	/	28	1,077
23	/	25	1,087
26	/	29	1,115
24	/	27	1,125
22	/	25	1,136
21	/	24	1,143
19	/	22	1,158
24	/	28	1,167
22	/	26	1,182
22	/	27	1,227
21	/	26	1,238
20	/	25	1,250
19	/	24	1,263
21	/	27	1,286
20	/	26	1,300
22	/	29	1,318
21	/	28	1,333
23	/	31	1,348
20	/	27	1,350
19	/	26	1,368
21	/	29	1,381
22	/	31	1,409
20	/	29	1,450
17	/	25	1,471
19	/	28	1,474
18	/	27	1,500

Available ratios for SL90-20 Gearbox

Gears			Ratio
19	/	29	1,526
16	/	25	1,563
21	/	33	1,571
20	/	32	1,600
18	/	29	1,611
16	/	26	1,625
20	/	33	1,650
18	/	30	1,667
19	/	32	1,684
16	/	27	1,688
18	/	31	1,722
19	/	33	1,737
17	/	30	1,765
18	/	32	1,778
15	/	27	1,800
17	/	31	1,824
18	/	33	1,833
19	/	35	1,842
17	/	32	1,882
18	/	34	1,889
14	/	27	1,929
18	/	35	1,944
16	/	32	2,000
18	/	37	2,056
14	/	29	2,071
16	/	34	2,125
15	/	32	2,133
13	/	28	2,154
15	/	33	2,200
13	/	29	2,231
16	/	36	2,250
15	/	34	2,267
16	/	37	2,313
14	/	33	2,357
16	/	38	2,375
12	/	29	2,417
14	/	34	2,429
14	/	35	2,500
13	/	33	2,538
15	/	39	2,600
13	/	34	2,615
15	/	40	2,667
12	/	33	2,750
13	/	36	2,769

on input shaft

Available ratios for SL90-20 Gearbox

Gears			Ratio
12	/	35	2,917
12	/	36	3,000
12	/	37	3,083
11	/	34	3,091
11	/	35	3,182
11	/	37	3,364
11	/	38	3,455
11	/	39	3,545
10	/	36	3,600
10	/	40	4,000